



Best Solution Lithium Battery

**BSLBATT 15KW
Slimline & VICTRON
Installation Manual
V1.3**



victron energy
BLUE POWER

SAFETY GUIDELINES




Work or maintenance on the BSLBatt should be carried out by qualified personal only.

Do not attempt to open or dismantle battery and / or cells.



The electrolyte contained in the battery cells is highly corrosive. In the event of any damage to or leakage from cells, treat contents with care, do not allow contact with exposed skin or eyes. **DO NOT INGEST!**



The Terminals of the BSLBatt should always be considered live, therefore do not place tools or any other items across the terminals. Do not pierce, short or damage the terminals in any way. Do not touch the terminals of the battery.



Fire Hazard: Do not discharge battery below specified minimum level as this poses an increased fire risk. Do not attempt to charge a swollen or damaged battery. In the event of a fire, a CO₂ or Dry Powder extinguisher should be used. Class D extinguishers are not suitable.



Dispose of batteries through the proper local regulations. Not suitable for regular refuse / recycling.

Contents

SAFETY GUIDELINES	i
Contents.....	ii
1. Pin-out Diagram	1
2. Battery Set-up.....	2
2.1 General.....	2
2.1.1 Turning battery on & Off.....	2
2.1.2 CAN Communication	2
2.1.3 Dry Contacts.....	2
2.1.4 Other Ports.....	2
2.2 Multiple Batteries	3
2.2.1 Max Number of Parallel Batteries	3
2.2.2 Installing Multiple Batteries.....	3
2.2.3 Cable Sizing with Multiple Batteries.....	3
2.2.4 Dip Switch Settings for Multiple Batteries (5.1 kWh, 6.4 kWh, 10.2kWh)	3
2.2.5 Dip Switch Settings for Multiple Batteries (8.2 kWh, 15 kWh).....	4
3. Inverter Set-up.....	5
3.1 Batteries Per Inverter Size.....	5
3.1.1 5.1 kWh (100 Ah)	5
3.1.2 6.4 kWh (125 Ah)	5
3.1.3 7 kWh (135 Ah).....	5
3.1.4 8.2 kWh (160 Ah)	5
3.1.5 8.8 kWh (172 Ah)	6
3.1.6 10.2 kWh (200 Ah)	6
3.1.7 15 kWh (300 Ah)	6
3.2 Battery Set-up on Victron GX Device	7
3.3 Battery Set-up on Victron MPPT Device	8
4. Inverter Settings (Victron).....	9
4.1 General Tab	9
4.2 Grid Tab.....	10
4.3 Inverter Tab	11
4.4 Charger Tab	12
4.5 Assistant Tab (a).....	14
4.6 Assistant Tab (b).....	15
4.7 Assistant Tab (c)	16
4.8 Assistant Tab (d).....	17
4.9 Assistant Tab (e).....	18
4.10 Assistant Tab (f).....	19
5. Revision History.....	20

1. Pin-out Diagram




Figure 1: Pin-out diagram for 5.1kWh BSL Battery.

A	Negative terminal
B	RS485 Left port (Port 1)
C	CAN Port (Port 2)
D	RS232 (Port 3)
E	RS485 Right Ports (Ports 4)
F	RS485 Right Ports (Ports 5)
G	Dry Contacts (mostly unused)
H	Dip switches for parallel connection
I	Reset switch (BMS Power button)
J	Positive terminal
K	Reset switch
L	Run light (battery activity)
M	Power light
N	Alarm indicator light
O	State Of Charge indicator LED'S
P	Circuit breaker (terminal power)

2. Battery Set-up

2.1 General

2.1.1 Turning battery on & Off

The battery can be switched on or off by holding down the small recessed button marked "RESET" for around 3 seconds.

2.1.2 CAN Communication


A VE.Can to CAN-bus BMS "Type B" cable is required for CAN-Bus communication between the BSL battery and the Victron GX device. Some inverters will use different cable configuration, please check this with inverter suppliers. (Black to inverter/GX device, red to battery).

Function	Victron <u>VE.Can</u> Side (GX)	Battery side
GND	Pin 3	Pin 2
CAN - L	Pin 8	Pin 5
CAN - H	Pin 7	Pin 4

2.1.3 Dry Contacts

Dry Contacts are mostly unused, but for communication with some non-smart systems please see the table below. Working current should be less than 2A, mainly to connect with an external indicator light or buzzer

PIN1 to PIN2	Always open, will close with low battery signal
PIN3 to PIN4	Always Open, will close with fault/protection signal.



2.1.4 Other Ports

Port 1 (RS485) and port 3 (RS232) are used for programming and retrieving information only and must be left open.

2.2 Multiple Batteries

2.2.1 Max Number of Parallel Batteries

A maximum of 30 batteries can be connected in parallel. Each battery will require a unique binary address which can be setup via the dip-switches located on the front of the battery.

2.2.2 Installing Multiple Batteries

When installing more than one battery in parallel, a standard RJ45 patch network cable will be required for inter-battery communication. These cables will need to be connected to port 4 or 5 between all the connected batteries. The ports are paralleled therefore any port can be used for in or out connection.

2.2.3 Cable Sizing with Multiple Batteries

It is recommended to make use of a common rail bus-bar when more than 4 batteries are to be installed. All positive cables running between the battery and bus-bar must be the same length and all negative cables must be the same length. The batteries should be evenly grouped where possible.

The recommended battery cable sizes from the batteries (going to the inverter) in parallel are as follows: 1 battery - 35mm², 2 batteries - 50mm², 3 batteries 70mm² or 2 × 35mm², 4 batteries - 95mm² or 2 × 50mm²

2.2.4 Dip Switch Settings for Multiple Batteries (5.1 kWh, 6.4 kWh, 10.2kWh)

Table 1: Dip-switch set-up for multiple batteries

Address	DIP Switch Position				Notes
	#1	#2	#3	#4	
-					-
1	ON	OFF	OFF	OFF	Master Pack
2	OFF	ON	OFF	OFF	Auxiliary Pack 1
3	ON	ON	OFF	OFF	Auxiliary Pack 2
4	OFF	OFF	ON	OFF	Auxiliary Pack 3
5	ON	OFF	ON	OFF	Auxiliary Pack 4
6	OFF	ON	ON	OFF	Auxiliary Pack 5
7	ON	ON	ON	OFF	Auxiliary Pack 6
8	OFF	OFF	OFF	ON	Auxiliary Pack 7
9	ON	OFF	OFF	ON	Auxiliary Pack 8
10	OFF	ON	OFF	ON	Auxiliary Pack 9
11	ON	ON	OFF	ON	Auxiliary Pack 10
12	OFF	OFF	ON	ON	Auxiliary Pack 11
13	ON	OFF	ON	ON	Auxiliary Pack 12
14	OFF	ON	ON	ON	Auxiliary Pack 13
15	ON	ON	ON	ON	Auxiliary Pack 14

2.2.5 Dip Switch Settings for Multiple Batteries (8.2 kWh, 15 kWh)

Table 2 Dip-switch set-up for multiple batteries

Address	DIP Switch Position						Notes
	#1	#2	#3	#4	#5	#6	
-							-
1	ON	OFF	OFF	OFF	OFF	OFF	Master Pack
2	OFF	ON	OFF	OFF	OFF	OFF	Auxiliary Pack 1
3	ON	ON	OFF	OFF	OFF	OFF	Auxiliary Pack 2
4	OFF	OFF	ON	OFF	OFF	OFF	Auxiliary Pack 3
5	ON	OFF	ON	OFF	OFF	OFF	Auxiliary Pack 4
6	OFF	ON	ON	OFF	OFF	OFF	Auxiliary Pack 5
7	ON	ON	ON	OFF	OFF	OFF	Auxiliary Pack 6
8	OFF	OFF	OFF	ON	OFF	OFF	Auxiliary Pack 7
9	ON	OFF	OFF	ON	OFF	OFF	Auxiliary Pack 8
10	OFF	ON	OFF	ON	OFF	OFF	Auxiliary Pack 9
11	ON	ON	OFF	ON	OFF	OFF	Auxiliary Pack 10
12	OFF	OFF	ON	ON	OFF	OFF	Auxiliary Pack 11
13	ON	OFF	ON	ON	OFF	OFF	Auxiliary Pack 12
14	OFF	ON	ON	ON	OFF	OFF	Auxiliary Pack 13
15	ON	ON	ON	ON	OFF	OFF	Auxiliary Pack 14
16	OFF	OFF	OFF	OFF	ON	OFF	Auxiliary Pack 15
17	ON	OFF	OFF	OFF	ON	OFF	Auxiliary Pack 16
18	OFF	ON	OFF	OFF	ON	OFF	Auxiliary Pack 17
19	ON	ON	OFF	OFF	ON	OFF	Auxiliary Pack 18
20	OFF	OFF	ON	OFF	ON	OFF	Auxiliary Pack 19
21	ON	OFF	ON	OFF	ON	OFF	Auxiliary Pack 20
22	OFF	ON	ON	OFF	ON	OFF	Auxiliary Pack 21
23	ON	ON	ON	OFF	ON	OFF	Auxiliary Pack 22
24	OFF	OFF	OFF	ON	ON	OFF	Auxiliary Pack 23
25	ON	OFF	OFF	ON	ON	OFF	Auxiliary Pack 24
26	OFF	ON	OFF	ON	ON	OFF	Auxiliary Pack 25
27	ON	ON	OFF	ON	ON	OFF	Auxiliary Pack 26
28	OFF	OFF	ON	ON	ON	OFF	Auxiliary Pack 27
29	ON	OFF	ON	ON	ON	OFF	Auxiliary Pack 28
30	OFF	ON	ON	ON	ON	OFF	Auxiliary Pack 29

3. Inverter Set-up

3.1 Batteries Per Inverter Size

3.1.1 5.1 kWh (100 Ah)

Inverter Size	Recommended Batteries	Minimum Batteries
15 kVA	4	3
10 kVA	3	2
8 kVA	2	2
5 kVA	2	1
3 kVA	1	1

3.1.2 6.4 kWh (125 Ah)

Inverter Size	Recommended Batteries	Minimum Batteries
15 kVA	4	3
10 kVA	3	2
8 kVA	2	2
5 kVA	2	1
3 kVA	1	1

3.1.3 7 kWh (135 Ah)

Inverter Size	Recommended Batteries	Minimum Batteries
15 kVA	4	3
10 kVA	3	2
8 kVA	2	2
5 kVA	2	1
3 kVA	1	1

3.1.4 8.2 kWh (160 Ah)

Inverter Size	Recommended Batteries	Minimum Batteries
15 kVA	3	2
10 kVA	2	2
8 kVA	2	1
5 kVA	1	1
3 kVA	1	1

3.1.5 8.8 kWh (172 Ah)

Inverter Size	Recommended Batteries	Minimum Batteries
15 kVA	3	2
10 kVA	2	2
8 kVA	2	1
5 kVA	1	1
3 kVA	1	1

3.1.6 10.2 kWh (200 Ah)


Inverter Size	Recommended Batteries	Minimum Batteries
15 kVA	4	3
10 kVA	3	2
8 kVA	2	2
5 kVA	2	1
3 kVA	1	1

3.1.7 15 kWh (300 Ah)

Inverter Size	Recommended Batteries	Minimum Batteries
15 kVA	2	2
10 kVA	2	1
8 kVA	1	1
5 kVA	1	1
3 kVA	1	1

3.2 Battery Set-up on Victron GX Device

1. The VE.Can to CAN-bus BMS Type B cable needs to be connected to the VE-Can port on the GX device and the second unused VE.Can port needs to be terminated with the Victron blue terminator. Ensure that the cable is marked CCGX at the end.
2. Press the enter button on the GX device. This should take you to the device list page. Scroll down to settings, press enter, and scroll to services and press enter again. Navigate to the CAN settings and change the CAN speed from 250 KB to 500 KB.
3. Scroll to DVCC and select Switch DVCC on. Flag SHARED VOLTAGE SENSE and CHARGE LIMIT. Set CCL (charge current limit) to 50% of battery capacity.
4. Navigate back to the device list and the BSL battery should appear on the device list.
5. Select the BSL battery set the parameters as follows:
 - Charge Voltage 54.5V.
 - Charge Current Limit: 150A per battery. (Recommended 100Ah)
 - Discharge Current Limit: 150A per battery. (Recommended 100Ah)





3.3 Battery Set-up on Victron MPPT Device

The screenshot displays the 'Settings' menu of a Victron MPPT device. The top status bar shows VoWiFi, 4G, signal strength, Wi-Fi, and a battery icon at 75% with the time 12:23. The settings are organized into sections:

- Battery voltage:** 48V (dropdown)
- Max charge current:** 100A
- Charger enabled:**
- Battery preset:** User defined (dropdown)
- Expert mode:**
- BMS controlled:** Yes >
- Charge voltages section:**
 - Absorption voltage: 55.00V
 - Float voltage: 54.80V
 - Equalization voltage: 54.00V
- Equalization section:**
 - Automatic equalization: Disabled
 - Manual equalization: [START NOW](#)
- Voltage compensation section:**
 - Temperature compensation: Disabled
- Battery limits section:**
 - Low temperature cut-off: 2°C

4. Inverter Settings (Victron)

4.1 General Tab



4.2 Grid Tab

VE Configure 3 (Quattro-II 48/5000/70-2x50)

File Port selection Target Defaults Options Special Help

General Grid Inverter Charger Virtual switch Assistants

Grid code selection

Country / grid code standard

Other: not compliant to any grid code standard

Show IP (NS) protection log

AC input related settings

AC input 1 Above selected gridcode plus LOM B (safe)

AC input 2 Above selected gridcode plus LOM B (safe)

Note: Click [here](#) for more info on LOM.

Transfer switch

Accept wide input frequency range (45-65 Hz)

AC low disconnect 205 V AC high connect 253 V

AC low connect 212 V AC high disconnect 258 V

UPS function

Changes require reset

4.3 Inverter Tab

VE Configure 3 (Quattro-II 48/5000/70-2x50)

File Port selection Target Defaults Options Special Help

General Grid **Inverter** Charger Virtual switch Assistants

Quattro-II

Freq. Out --- Hz
UOut --- V
IOut --- A

Freq. In --- Hz
UMains --- V
IMains --- A

Udc --- V
Udc ripple --- V
Idc --- A

SoC

Ignore AC aux. relay ---

Get settings

Send settings

Victron Energy

Inverter output voltage 230 V

Ground relay

DC input low shut-down 48.00 V

DC input low restart 52.50 V

DC input low pre-alarm 51.00 V

PowerAssist

Assist current boost factor 2.0

shut-down on SOC

SOC low shut-down 0.0 %

SOC low restart 0.0 %

Do not restart after short-circuit (VDE 2510-2 safety)

enable AES

Start AES when load lower than 92 W

Stop AES when load 46 W higher than start level

AES type

modified sine wave



search mode

1s

Changes require reset

Take Note: shut-down on SOC unticked so as to use voltage for battery monitoring.

4.4 Charger Tab





4.5 Assistant Tab (a)


The screenshot displays the 'VE Configure 3' software window for a Quattro-II 48/5000/70-2x50. The interface is divided into several sections:

- Left Panel (Quattro-II):** Contains various status indicators and settings:
 - Freq. Out: --- Hz
 - UOut: --- V
 - IOut: --- A
 - Freq. In: --- Hz
 - UMains: --- V
 - IMains: --- A
 - Udc: --- V
 - Udc ripple: --- V
 - Idc: --- A
 - SoC: A progress bar with 5 segments, the first is red.
 - Ignore AC aux. relay: ---
- Bottom Left:** Features the Victron Energy logo and two buttons: 'Get settings' and 'Send settings'.
- Top Menu:** Includes 'File', 'Port selection', 'Target', 'Defaults', 'Options', 'Special', and 'Help'.
- Assistant Configuration Tab:** The active tab, containing:
 - 'Assistant Setup' section with an 'Add assistant' button.
 - A list box containing 'ESS (Energy Storage System)'.
 - Navigation arrows (up and down) on the right side of the list box.
 - 'Used assistants: (approx. 57 bytes used)' text below the list box.
 - Buttons for 'Start assistant', 'Save assistant', 'Delete assistant', 'Summary', and 'Load assistant'.
- Bottom Status Bar:** Displays an information icon and the text 'Changes require reset'.

4.6 Assistant Tab (b)




4.7 Assistant Tab (c)



4.8 Assistant Tab (d)



4.9 Assistant Tab (e)



The screenshot shows the VEConfigure 3 software interface for an ESS (Energy Storage System). A dialog box titled "Dynamic cut-off" is open, providing instructions and a table of cut-off voltages. The background window shows various configuration parameters for the Quattro-II system.

Dynamic cut-off
This assistant uses so called dynamic cut-off. That is, the 'DC input low shut-down' level depends on the battery discharge current.

There will normally be no need to adjust the curve used for this! Just accept below values which are already optimized for the selected battery type.

In rare cases it might be advantageous to modify the curve. This can be done by changing the values below.

Note:
* Because dynamic cut-off is used, the "DC input low shut-down" related parameters in VEConfigure are ignored.

Cut off voltage for a discharge current of:	
0.005 C	= 47.00 V
0.25 C	= 47.00 V
0.7 C	= 47.00 V
2 C	= 47.00 V

Buttons: Cancel, <<, >>, Summary, Load assistant

Changes require reset

4.10 Assistant Tab (f)

The screenshot shows the VE Configure 3 software interface for a Quattro-II 48/5000/70-2x50. The 'Assistants' tab is active, and the 'ESS (Energy Storage System)' window is open. The 'Restart offset' parameter is being configured. The text in the window reads: "When inverting is stopped due to low battery, the battery voltage must rise above a certain level before inverting is allowed again. This level is determined as an offset to cut-off(0). (cut-off(0) is the cut-off voltage corresponding with a DC discharge of 0A.)" A note states: "Note: This same value is used as an offset to the cut-off voltage to determine the low bat Pre-Alarm indication)". The current value is set to 1.20 V. The interface includes a 'Cancel' button, navigation arrows, and a 'Changes require reset' warning at the bottom.

VE Configure 3 (Quattro-II 48/5000/70-2x50)

File Port selection Target Defaults Options Special Help

General Grid Inverter Charger Virtual switch Assistants

Quattro-II

ESS (Energy Storage System)

Restart offset

When inverting is stopped due to low battery, the battery voltage must rise above a certain level before inverting is allowed again. This level is determined as an offset to cut-off(0). (cut-off(0) is the cut-off voltage corresponding with a DC discharge of 0A.)

Note:
This same value is used as an offset to the cut-off voltage to determine the low bat Pre-Alarm indication)

Inverting is allowed again when voltage rises V above cut-off(0).

Cancel << >>

Summary Load assistant

Changes require reset

5. Revision History

Version	Date	Editor	Changes
1	Nov 2021	D. E. Cornew	-
1.1	Feb 2022	P. J. Andrew	- Address 0 column removed from Dip switch settings for multiple batteries (Tables 1 and 2) - Formatting
1.2	Nov 2022	P.J. Andrew D. E. Cornew	- Update on BSLBatt Branding. - Formatting. - Update VE.Configure Inverter Tab. (4.3) - Update VE.Configure Charger Tab. (4.4) - Updated to include 300Ah
1.3	Jun 2023	P.J. Andrew, N. Jones	- Format overhaul - Readded Images. - Removed 4.11 & 4.12